

### DESKTOP CHARGER BC-160

#### PRECAUTIONS

- **⚠ DANGER!** Charge specified Icom battery packs only. The charger has been tested and approved for use with only genuine Icom battery packs. Fire and/or explosion may occur when trying to charge a third party or counterfeit battery pack.
  - **⚠ DANGER! KEEP** battery packs away from fire. Fire or heat may cause them to rupture or explode. Dispose of used battery packs in accordance with local regulations.
  - **⚠ USE INDOORS ONLY! NEVER** expose the charger to rain, snow or any liquids.
  - **⚠ WARNING! NEVER** disassemble the charger. Incorrect reassembly may result in a fire hazard or electric shock.
  - **⚠ WARNING! NEVER** let metal, wire, and so on touch any internal parts of the charger.
  - **CAUTION: NEVER** insert a battery pack or a transceiver (with the battery pack attached) in a wet or soiled condition into the charger. This may result in corrosion of the charger terminals or damage to the charger. The charger is not waterproof and water can easily get into it.
  - **CAUTION: NEVER** use the charger when it is covered with objects that do not allow heat to escape.
  - Place the charger in a secure place to avoid inadvertent use by children.
  - **DO NOT** charge in conditions of extreme cold (under 0°C; +32°F) or extreme heat (over +45°C; +113°F). Battery packs may not charge under extreme temperatures.
  - **Keep** the charger away from TV sets or radios to prevent interference.
  - **SAVE THIS INSTRUCTION SHEET.** These instructions contain important safety and operating details for the BC-160.
- /// Make sure the battery and charger contacts are always clean, otherwise battery packs may not charge completely.
- /// If your battery packs seem to have no capacity even after being fully charged, charge them again. If they still do not retain a charge (or very little), purchase new one.

Icom is not responsible for the destruction, damage to, or performance of any Icom or non-Icom equipment, if the malfunction is because of:


- Force majeure, including, but not limited to, fires, earthquakes, storms, floods, lightning, other natural disasters, disturbances, riots, war, or radioactive contamination.
- The use of Icom transceivers with any equipment that is not manufactured or approved by Icom.

Thank you for purchasing the BC-160 DESKTOP CHARGER. The BC-160 charges a Li-ion battery pack in approximately 1.5–3.5 hours.

Please read these instructions thoroughly before using the BC-160.


#### BATTERY PACK CHARGING

AC adapter  
(A different type, or no AC adapter is supplied, depending on the version.)



#### IMPORTANT!

Ensure the guide tabs on the battery pack are correctly aligned with the guide rails in the charger.



#### • Approximate charging time

BP-230/N:	1.5 hours
BP-231:	2 hours
BP-232/N:	3 hours
BP-232H/WP:	3.5 hours

#### • LED indication

Orange:	Lights while rapid charging.
Green:	Lights when charging is completed.
Red (blink):	The inserted battery pack or the charger has a problem.

/// When the LED indicator does not light, even after a battery pack is inserted properly, the battery pack may have a problem.

Icom, Icom Inc. and the Icom logo are registered trademarks of Icom Incorporated (Japan) in Japan, the United States, the United Kingdom, Germany, France, Spain, Russia, Australia, New Zealand, and/or other countries.